

Installation instructions Revised 02/01/2010

*****Please

NOTE: These installation instructions will work with BOTH the SR-1800 and the SR-3500/6500

1. Download the file from the Sekonic website if you don't already have it.
2. Right click on the Sekonic.Zip file you want to extract- Choose the extract all option
3. Follow through with the extraction - Noting the location of the extraction of the files - It is important that you extract the files. The files will not act properly until there extracted into a folder. The default folder that that the zip extracts too is the folder that the zip file is in.
4. Plug in the scanner - you will get a "found new hardware wizard". Click on the radio button that says "Do not check the web for a driver" - click next.
5. Now choose the option to "install from a specific location" - click next
6. Make sure the radio button "Search for drivers in these locations" is checked
7. Make sure the "Include this location in the search" is checked
8. Now you will notice that the grey box under the check box is white and you can click on the "browse" button
9. Click on the browse button and a window will pop open with a folder structure.
10. Navigate to the folder that you extracted the files too - ie: 1800 . The folder is the one documented above during the file extraction - example C:\Documents and Settings\JustinTech\My Documents\SR-1800CD\SR-1800CD\Driver and click OK
11. Now click next. - the driver should start to install itself. If it installed properly than the hardware wizard will let you know that the driver installed correctly. If it didn't install correctly than it will ask you to find the driver again.

*Please make note that you must point the driver wizard to the correct /1800/drivers/ folder or the driver will not be installed and the wizard will ask you to find the driver again.

Copyright Sekonic 2010 - All Rights Reserved